



Hard to find parts for your vintage N600, Z600, 360, and more.  
[www.honda600store.com](http://www.honda600store.com)

## RECTIFIER TESTING

- 1) Disconnect rectifier everywhere (gnd may stay connected)
- 2) Set Volt Meter to Diode Test Mode
- 3) Connect Probes as below (6 tests, note correct probe polarity):

Pos	Neg	Indicated Value
A	V+	0.54 (+/-0.2)
B	V+	0.54
C	V+	0.54
V-	A	0.54
V-	B	0.54
V-	C	0.54

